




## Instructions



Charging: DC 5V1A

Press Button:  
1X:100% 2X:50%  
3X:25% 4X:OFF




Clockwise rotation


## 3-STEP MOODMAKER™



300lm



150lm



75lm

### Warning

\* This luminaire has been designed to be used in operating temperatures between -10° and +50°C. If luminaire is used in other ambient temperatures, the life of the battery may be reduced and not work properly. Don't leave this product under direct sunlight.

\* When replacing the battery, replace the battery with the same specifications as indicated on the supplied battery.